

Table of Contents

1. Introduction	
Mainboard Features	1-1
Mainboard Description	1-1
Specification	1-2
Mainboard Layout	1-4
2. Installation	
Check List	2-1
Dimensions	2-2
Install Main Memory	2-2
Memory Configuration Table	2-3
Cache Memory	2-5
Install CPU	2-6
CPU frequency and Bus frequency of Intel Petium® processor or Intel Pentium® processor with MMX™ technology	2-6
CPU Fan	2-8
Install Fan Power On-board	2-8
Green LED	2-9
Install Cables	2-9
IDE Connector	2-9
Floppy Disk Connector	2-10
IrDA	2-10
USB Header	2-11
H.D.D. LED	2-11
20-pin Front Panel Switch Connector	2-12
Power Supply Connector	2-12
AT Keyboard Connector	2-13
PS/2 Mouse & Keyboard Connector	2-13
Serial Port COM1 and COM2	2-14
Parallel Port Printer Connector	2-14
Install Add-on Card	2-15
Other Jumpers	2-15
Clear CMOS (JP4) and Clear Password (JP1)	2-15
Summary	2-16
Connector Table	2-17
3. Built-in BIOS Setup Program	
SETUP Program	3-1
Standard CMOS Setup	3-3
BIOS Features Setup	3-4
Chipset Features Setup	3-6
Power Management Setup	3-9
PNP/PCI Configuration Setup	3-11
Load BIOS Defaults	3-12
Load Optimum Setting	3-12
Integrated Peripherals	3-13
Supervisor Password	3-15
User Password	3-15
IDE HDD Auto Detection	3-16
Quitting SETUP	3-17
Appendix A	Appendix A-1
Appendix B	Appendix B-1
Appendix C	Appendix C-1

About this Manual

This manual is designed to offer detailed information about the P5TX-B mainboard. The content includes the main features of the mainboard, the installation , and the BIOS settings. There are three chapters to offer clear and detailed information of P5TX-B.

- | | |
|------------------|---|
| Chapter 1 | Introduction
Describes the main features and major components. |
| Chapter 2 | Installation
Describes the installation of hardware including jumpers , cables and connectors. |
| Chapter 3 | BIOS Setup
Describes the setup of BIOS. Briefly explain each item and show the selection of option. |

Warning Marks

In this manual , **warning marks** are used to stress important parts or notices of text that require users' attention. There are two kinds of warning marks in this manual:




Stress the important information or instructions that must pay more attentions to and should be noted.




Avoid the possible system error or damages , and offer detailed information.

Graphic Descriptions of Jumper Settings



means Pin 1 & Pin 2 are set as short



means Pin 1 & Pin 2 are set as open